






OVISLINK

Call Center Headset OVHS084-CSP

User Manual



Package Contents:

- 1 Unit of OvisLink Dual Ear Headset
- 1 Unit of OvisLink RJ9 Quick Disconnect Cord
- 1 Unit of OvisLink 2.5mm Quick Disconnect Cord


Features:

- 1) Adjustable Headband - Headband adjusts to the desired length and stays in position.
- 2) Turnable Earpiece - Earpiece can be turned within 20° to fit with user's ear.
- 3) Adaptable Earpiece – Earpiece adapts to the user's ear moving up and down to align with user's head and ear structure for comfort.
- 4) Two Earpieces - Two earpieces on user's both ears help user focus on phone conversation.
- 5) Soft, Smooth Leatherette Ear cushion - Very smooth leatherette ear cushion lets user feel comfortable for long periods of time.
- 6) Rotatable Microphone Boom - Microphone boom can be rotated 270°, user may place the headset speaker on the left or right ear anytime as he/she wants.
- 7) Manageable Microphone stem - Microphone stem is manageable. User may adjust the microphone to the desired spot and it will stay in place.
- 8) Quick Disconnect - The headset cord can be disconnected at the middle, just simply unplug it. Unplugging on and off will not drop the call.
- 9) RJ9 Connector - One Quick Disconnect cord with RJ9 that connects the headset directly to Cisco Unified IP phones.
- 10) 2.5mm Connector - One Quick Disconnect cord with 2.5mm connector that connects the headset with Cisco SPA series Small Business IP phones.
- 11) Clothing Clip – User can clip the headset cord to his/her shirt for stability using the clothing clip.
- 12) Tangle-less headset cord - The headset cord is tangle-less, will not twist even use it for long time.
- 13) Long headset cord - Upper cord + Coiled Quick Disconnect cord is about 5 ft long and can be stretched to 7 ft.

Instruction:


1. Choose the right quick disconnect cord and connect it to the phone's headset jack

- a) For **Cisco Unified IP phone models**, choose the **RJ9 Quick Disconnect Cord** and connect it to back of the phone as picture below:




Back of Cisco Unified Phone

- b) For **Cisco SPA Small Business IP phones**, choose the **2.5mm Quick Disconnect Cord** and connect it to the low right hand side of the phone:



2. Connect the headset with the quick disconnect cord




3. Adjust the length of the headband and turn the earpieces slightly until the headset fits comfortably.
4. Rotate the microphone boom to put the microphone in front of the mouth.
5. To optimize the position of the microphone, adjust the microphone stem in either direction so the microphone is close to the corner of your mouth and the white dot at the microphone should be facing to your mouth.
6. Attach the clothing clip at a comfortable level to keep the headset properly positioned and free from the cord's weight.

7. Press the headset key on the telephone keypad to get dial tone to the headset, answer an incoming call and disconnect call.

Cisco Unified IP Phone Models keypad



Cisco SPA Series Phone Keypad



*** OvisLink headset model OVHS084-CSP is special designed for Cisco IP phones. If you have other telephone brand or any problem, please contact OvisLink at support@ovislink.com